



**SDC Laboratory**

Tierra del Sol Industrial Park - 2329 Lava Lane  
PO Box 642, Alamosa, CO 81101  
Phone: 719-589-1024  
Email: juliez@sangrelabs.com  
www.sdclaboratory.com

## Chain of Custody

**PAYMENT IS DUE AT TIME OF SAMPLE DROP-OFF. NO EXCEPTIONS.**

### PLEASE FILL OUT INFORMATION BELOW

Client Name/Contact: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Address of Sample: \_\_\_\_\_

Date Collected: \_\_\_\_\_

Time Collected: \_\_\_\_\_

Collected By: \_\_\_\_\_

Email for results: \_\_\_\_\_

Signature (Relinquished by): \_\_\_\_\_

Date/Time: \_\_\_\_\_

- Analysis(es) Requested:**
- Private Well Package** (includes bacteria, alkalinity hardness, chloride, fluoride, nitrate, nitrite, phosphate, sodium, sulfate, total dissolved solids, pH, arsenic, cadmium, copper, iron, lead, and manganese) \$240
  - Loan Package** (includes bacteria, nitrate, nitrite, and lead) \$120
  - Bacteria Only \$42**
  - Other** \_\_\_\_\_
- ALL PRICES SUBJECT TO CHANGE*

### FOR LAB USE ONLY

Received by: \_\_\_\_\_

Date/Time: \_\_\_\_\_ Lab Sample Number: \_\_\_\_\_

**Thank you! We appreciate you and are always here to help!**



Tierra del Sol Industrial Park - 2329 Lava Lane  
PO Box 642, Alamosa, CO 81101  
Phone: 719-589-1024  
Email: juliez@sangrelabs.com  
www.sdclaboratory.com

## **PROPER SAMPLE COLLECTION IS IMPORTANT - PLEASE USE INSTRUCTIONS BELOW TO ENSURE BEST RESULTS**

### ***FOR PRIVATE WELL & LOAN PACKAGES (Three bottle numbered set)***

**1. PREPARATION:** Be sure to wash your hands with soap and warm water prior to collecting sample. Remove any filtration equipment/screens and thoroughly disinfect faucet with rubbing alcohol or bleach. Use *ONE* faucet to collect water for *ALL THREE* bottles.

**2. COLLECT BOTTLE #1:** For Bottle #1, collect in the morning before any faucets have been turned on or toilets flushed.

**3. COLLECT BOTTLES #2 AND #3:** After collecting Bottle #1, run the water for 2-3 minutes then collect Bottle #2 and Bottle #3. Fill *Bottle #3* to '*Fill Line*' indicated on the bottle. Samples under the '*Fill Line*' are subject to rejection. Take care NOT to touch the bottle opening or inside the bottle. Do not rinse bottle before collection. Samples need to be kept cool and delivered to the lab within 24 hours.

**4. SUPPLEMENTAL PAPERWORK:** Complete this form and clearly write your name on your sample bottle.

### ***FOR BACTERIA SAMPLES (Flip top bottle with pill/powder inside)***

**1. PREPARATION:** Be sure to wash your hands with soap and warm water prior to collecting sample. Remove any filtration equipment/screens and thoroughly disinfect faucet with rubbing alcohol or bleach.

**2. COLLECTION:** Let water run for 2-3 minutes and then collect sample. Fill bottle to '*Fill Line*' indicated on the bottle. Samples under the '*Fill Line*' are subject to rejection. Take care NOT to touch the bottle opening or inside the bottle. Do not rinse bottle before collection. Samples need to be kept cool and delivered to the lab within 24 hours.

**3. SUPPLEMENTAL PAPERWORK:** Complete this form and clearly write your name on your sample bottle.

**\*Payment is due at time of sample drop-off\***

### ***FOR ALL OTHER SAMPLES (If in doubt, call us)***

**1. COLLECT SAMPLE:** Collect sample from desired location. Samples need to be kept cool and delivered to the lab within 24 hours.

**2. SUPPLEMENTAL PAPERWORK:** Complete this form and clearly write your name on your sample bottle.

**Thank you! We appreciate you and are always here to help!**